


Multi-Channel Encoding Monitor (MCEM)

Encodability View and Detectability Confidence History Files

To download the Encodability View or Detectability Confidence history files the following steps must be completed:


1. Verify the computer is connected to your LAN and the MCEM via the rear panel ethernet port.
2. Identify the MCEM's IP address. This can be found via the front panel LCD display. From the front panel, press the top arrow 3 times.
3. Open a web browser (Microsoft Internet Explorer®, Firefox®, Chrome™, Opera®, or Safari®) on the computer connected to the monitor and enter the following in the address window: https://IP-address
4. The login window will open. Enter the user name, **Station** (case-sensitive), and the password, **COLumb1aMD** (case-sensitive), and click the OK button.
5. Navigate to the menu item (Encodability View or Detectability Confidence).
6. At the bottom of the page click on the link to download.
7. A prompt will appear to save the zip file.
8. The file can be opened with Excel, Google Sheets, or other spreadsheet program.



For more information contact your Audio Client Engineer at 1-866-767-7212, or email encoding@nielsen.com

Multi-Channel Encoding Monitor (MCEM)

Encodability View and Detectability Confidence History Files



For more information contact your Audio Client Engineer at 1-866-767-7212, or email encoding@nielsen.com